

Ild. Nr.	Service Name	Provider	Type	Frequency	Symbolrate	Service ID	Transponder	Network ID
1	alt 1LIVE	ARD WDR	dig. Radio	114.000 MHz	6900	28475	1093	41028
2	alt 1LIVE diGGi	ARD WDR	dig. Radio	114.000 MHz	6900	28481	1093	41028
3	alt Antenne Brandenburg	ARD rbb	dig. Radio	114.000 MHz	6900	28454	1093	41028
4	alt Bayern 1	ARD BR	dig. Radio	114.000 MHz	6900	28400	1093	41028
5	alt Bayern 2	ARD BR	dig. Radio	114.000 MHz	6900	28401	1093	41028
6	alt BAYERN 3	ARD BR	dig. Radio	114.000 MHz	6900	28402	1093	41028
7	alt BR-KLASSIK	ARD BR	dig. Radio	114.000 MHz	6900	28403	1093	41028
8	alt BR Heimat	ARD BR	dig. Radio	114.000 MHz	6900	28407	1093	41028
9	alt BR Schlager	ARD BR	dig. Radio	114.000 MHz	6900	28405	1093	41028
10	alt BR24	ARD BR	dig. Radio	114.000 MHz	6900	28404	1093	41028
11	alt BR24live	ARD BR	dig. Radio	114.000 MHz	6900	28408	1093	41028
12	alt Bremen Eins	ARD RB	dig. Radio	114.000 MHz	6900	28448	1093	41028
13	alt Bremen Vier	ARD RB	dig. Radio	114.000 MHz	6900	28450	1093	41028
14	alt Bremen Zwei	ARD RB	dig. Radio	114.000 MHz	6900	28449	1093	41028
15	alt COSMO	ARD WDR	dig. Radio	114.000 MHz	6900	28480	1093	41028
16	alt DASDING	ARD SWR	dig. Radio	114.000 MHz	6900	28471	1093	41028
17	alt Die Maus	ARD WDR	dig. Radio	114.000 MHz	6900	28482	1093	41028
18	alt Fritz	ARD rbb	dig. Radio	114.000 MHz	6900	28457	1093	41028
19	alt hr-INFO	ARD HR	dig. Radio	114.000 MHz	6900	28424	1093	41028
20	alt hr1	ARD HR	dig. Radio	114.000 MHz	6900	28419	1093	41028
21	alt hr2	ARD HR	dig. Radio	114.000 MHz	6900	28420	1093	41028
22	alt hr3	ARD HR	dig. Radio	114.000 MHz	6900	28421	1093	41028
23	alt hr4	ARD HR	dig. Radio	114.000 MHz	6900	28422	1093	41028
24	alt Inforadio	ARD rbb	dig. Radio	114.000 MHz	6900	28452	1093	41028
25	alt MDR AKTUELL	ARD MDR	dig. Radio	114.000 MHz	6900	28434	1093	41028
26	alt MDR JUMP	ARD MDR	dig. Radio	114.000 MHz	6900	28432	1093	41028
27	alt MDR KLASSIK	ARD MDR	dig. Radio	114.000 MHz	6900	28435	1093	41028
28	alt MDR KULTUR	ARD MDR	dig. Radio	114.000 MHz	6900	28431	1093	41028
29	alt MDR S-ANHALT MD	ARD MDR	dig. Radio	114.000 MHz	6900	28429	1093	41028
30	alt MDR SACHSEN DD	ARD MDR	dig. Radio	114.000 MHz	6900	28428	1093	41028
31	alt MDR SPUTNIK	ARD MDR	dig. Radio	114.000 MHz	6900	28433	1093	41028
32	alt MDR THÜR Mitte-W	ARD MDR	dig. Radio	114.000 MHz	6900	28430	1093	41028
33	alt N-JOY	ARD NDR	dig. Radio	114.000 MHz	6900	28440	1093	41028
34	alt NDR 1 Nieders. HAN	ARD NDR	dig. Radio	114.000 MHz	6900	28444	1093	41028
35	alt NDR 1 Radio MV SN	ARD NDR	dig. Radio	114.000 MHz	6900	28443	1093	41028
36	alt NDR 2 NDS	ARD NDR	dig. Radio	114.000 MHz	6900	28437	1093	41028
37	alt NDR 90,3	ARD NDR	dig. Radio	114.000 MHz	6900	28441	1093	41028
38	alt NDR Blue	ARD NDR	dig. Radio	114.000 MHz	6900	28446	1093	41028
39	alt NDR Info NDS	ARD NDR	dig. Radio	114.000 MHz	6900	28439	1093	41028
40	alt NDR Info Spezial	ARD NDR	dig. Radio	114.000 MHz	6900	28445	1093	41028
41	alt NDR Kultur	ARD NDR	dig. Radio	114.000 MHz	6900	28438	1093	41028
42	alt NDR Plus	ARD NDR	dig. Radio	114.000 MHz	6900	28447	1093	41028
43	alt NDR1 Welle Nord KI	ARD NDR	dig. Radio	114.000 MHz	6900	28442	1093	41028
44	alt PULS	ARD BR	dig. Radio	114.000 MHz	6900	28406	1093	41028
45	alt radioeins	ARD rbb	dig. Radio	114.000 MHz	6900	28456	1093	41028
46	alt rbb 88.8	ARD rbb	dig. Radio	114.000 MHz	6900	28455	1093	41028
47	alt rbbKultur	ARD rbb	dig. Radio	114.000 MHz	6900	28453	1093	41028
48	alt SR 1 Europawelle	ARD SR	dig. Radio	114.000 MHz	6900	28461	1093	41028
49	alt SR 2 KulturRadio	ARD SR	dig. Radio	114.000 MHz	6900	28462	1093	41028
50	alt SR 3 Saarlandwelle	ARD SR	dig. Radio	114.000 MHz	6900	28463	1093	41028
51	alt SWR Aktuell	ARD SWR	dig. Radio	114.000 MHz	6900	28472	1093	41028
52	alt SWR1 BW	ARD SWR	dig. Radio	114.000 MHz	6900	28465	1093	41028
53	alt SWR1 RP	ARD SWR	dig. Radio	114.000 MHz	6900	28466	1093	41028
54	alt SWR2	ARD SWR	dig. Radio	114.000 MHz	6900	28467	1093	41028
55	alt SWR3	ARD SWR	dig. Radio	114.000 MHz	6900	28468	1093	41028
56	alt SWR4 BW	ARD SWR	dig. Radio	114.000 MHz	6900	28469	1093	41028
57	alt SWR4 RP	ARD SWR	dig. Radio	114.000 MHz	6900	28470	1093	41028
58	alt WDR 2 Rheinland	ARD WDR	dig. Radio	114.000 MHz	6900	28476	1093	41028
59	alt WDR 3	ARD WDR	dig. Radio	114.000 MHz	6900	28477	1093	41028
60	alt WDR 4	ARD WDR	dig. Radio	114.000 MHz	6900	28478	1093	41028
61	alt WDR 5	ARD WDR	dig. Radio	114.000 MHz	6900	28479	1093	41028
62	alt WDR Event	ARD WDR	dig. Radio	114.000 MHz	6900	28483	1093	41028
63	alt YOU FM	ARD HR	dig. Radio	114.000 MHz	6900	28423	1093	41028
64	ffn	MB Satellite	dig. Radio	122.000 MHz	6900	12654	1113	41028
65	harmony.fm	MB Satellite	dig. Radio	122.000 MHz	6900	12662	1113	41028
66	HIT RADIO FFH	MB Satellite	dig. Radio	122.000 MHz	6900	12660	1113	41028
67	planet radio	MB Satellite	dig. Radio	122.000 MHz	6900	12661	1113	41028
68	Radio Paloma	MB Satellite	dig. Radio	122.000 MHz	6900	12655	1113	41028
69	Schlager Radio	MB Satellite	dig. Radio	122.000 MHz	6900	12664	1113	41028
70	Schlager Radio	MB Satellite	dig. Radio	122.000 MHz	6900	12658	1113	41028
71	FM4	ORF	dig. Radio	138.000 MHz	6900	13134	1115	41028
72	OE1	ORF	dig. Radio	138.000 MHz	6900	13121	1115	41028
73	RADIO MARIA	Radio Maria Österreich	dig. Radio	138.000 MHz	6900	13140	1115	41028
74	U1 Tirol	U1 Tirol	dig. Radio	138.000 MHz	6900	13136	1115	41028
75	Dlf	ZDFvision	dig. Radio	546.000 MHz	6900	28013	1079	41028
76	Dlf Kultur	ZDFvision	dig. Radio	546.000 MHz	6900	28012	1079	41028
77	Dlf Nova	ZDFvision	dig. Radio	546.000 MHz	6900	28017	1079	41028
78	DRadio DokDeb	ZDFvision	dig. Radio	546.000 MHz	6900	28015	1079	41028
79	Antenne Brandenburg	ARD rbb	dig. Radio	570.000 MHz	6900	10486	1061	41028
80	Fritz	ARD rbb	dig. Radio	570.000 MHz	6900	10489	1061	41028
81	hr-INFO	ARD HR	dig. Radio	570.000 MHz	6900	10470	1061	41028

82	hr1	ARD HR	dig. Radio	570.000 MHz	6900	10465	1061	41028
83	hr2	ARD HR	dig. Radio	570.000 MHz	6900	10466	1061	41028
84	hr3	ARD HR	dig. Radio	570.000 MHz	6900	10467	1061	41028
85	hr4	ARD HR	dig. Radio	570.000 MHz	6900	10468	1061	41028
86	Inforadio	ARD rbb	dig. Radio	570.000 MHz	6900	10484	1061	41028
87	MDR AKTUELL	ARD MDR	dig. Radio	570.000 MHz	6900	10480	1061	41028
88	MDR JUMP	ARD MDR	dig. Radio	570.000 MHz	6900	10478	1061	41028
89	MDR KLASSIK	ARD MDR	dig. Radio	570.000 MHz	6900	10481	1061	41028
90	MDR KULTUR	ARD MDR	dig. Radio	570.000 MHz	6900	10477	1061	41028
91	MDR S-ANHALT MD	ARD MDR	dig. Radio	570.000 MHz	6900	10475	1061	41028
92	MDR SACHSEN DD	ARD MDR	dig. Radio	570.000 MHz	6900	10474	1061	41028
93	MDR SPUTNIK	ARD MDR	dig. Radio	570.000 MHz	6900	10479	1061	41028
94	MDR THÜR Mitte-W	ARD MDR	dig. Radio	570.000 MHz	6900	10476	1061	41028
95	radioeins	ARD rbb	dig. Radio	570.000 MHz	6900	10488	1061	41028
96	rbb 88.8	ARD rbb	dig. Radio	570.000 MHz	6900	10487	1061	41028
97	rbbKultur	ARD rbb	dig. Radio	570.000 MHz	6900	10485	1061	41028
98	YOU FM	ARD HR	dig. Radio	570.000 MHz	6900	10469	1061	41028
99	1LIVE	ARD WDR	dig. Radio	602.000 MHz	6900	10451	1039	41028
100	1LIVE diGGi	ARD WDR	dig. Radio	602.000 MHz	6900	10457	1039	41028
101	Bayern 1	ARD BR	dig. Radio	602.000 MHz	6900	10400	1039	41028
102	Bayern 2	ARD BR	dig. Radio	602.000 MHz	6900	10401	1039	41028
103	BAYERN 3	ARD BR	dig. Radio	602.000 MHz	6900	10402	1039	41028
104	BR-KLASSIK	ARD BR	dig. Radio	602.000 MHz	6900	10403	1039	41028
105	BR Heimat	ARD BR	dig. Radio	602.000 MHz	6900	10408	1039	41028
106	BR Schlager	ARD BR	dig. Radio	602.000 MHz	6900	10406	1039	41028
107	BR24	ARD BR	dig. Radio	602.000 MHz	6900	10404	1039	41028
108	BR24live	ARD BR	dig. Radio	602.000 MHz	6900	10405	1039	41028
109	Bremen Eins	ARD RB	dig. Radio	602.000 MHz	6900	10426	1039	41028
110	Bremen NEXT	ARD RB	dig. Radio	602.000 MHz	6900	10429	1039	41028
111	Bremen Vier	ARD RB	dig. Radio	602.000 MHz	6900	10428	1039	41028
112	Bremen Zwei	ARD RB	dig. Radio	602.000 MHz	6900	10427	1039	41028
113	COSMO	ARD WDR	dig. Radio	602.000 MHz	6900	10456	1039	41028
114	DASDING	ARD SWR	dig. Radio	602.000 MHz	6900	10446	1039	41028
115	Die Maus	ARD WDR	dig. Radio	602.000 MHz	6900	10458	1039	41028
116	N-JOY	ARD NDR	dig. Radio	602.000 MHz	6900	10415	1039	41028
117	NDR 1 Nieders. HAN	ARD NDR	dig. Radio	602.000 MHz	6900	10419	1039	41028
118	NDR 1 Radio MV SN	ARD NDR	dig. Radio	602.000 MHz	6900	10418	1039	41028
119	NDR 2 NDS	ARD NDR	dig. Radio	602.000 MHz	6900	10412	1039	41028
120	NDR 90,3	ARD NDR	dig. Radio	602.000 MHz	6900	10416	1039	41028
121	NDR Blue	ARD NDR	dig. Radio	602.000 MHz	6900	10421	1039	41028
122	NDR Info NDS	ARD NDR	dig. Radio	602.000 MHz	6900	10414	1039	41028
123	NDR Info Spezial	ARD NDR	dig. Radio	602.000 MHz	6900	10420	1039	41028
124	NDR Kultur	ARD NDR	dig. Radio	602.000 MHz	6900	10413	1039	41028
125	NDR Plus	ARD NDR	dig. Radio	602.000 MHz	6900	10422	1039	41028
126	NDR1 Welle Nord KI	ARD NDR	dig. Radio	602.000 MHz	6900	10417	1039	41028
127	PULS	ARD BR	dig. Radio	602.000 MHz	6900	10407	1039	41028
128	SR 1 Europawelle	ARD SR	dig. Radio	602.000 MHz	6900	10432	1039	41028
129	SR 2 KulturRadio	ARD SR	dig. Radio	602.000 MHz	6900	10433	1039	41028
130	SR 3 Saarlandwelle	ARD SR	dig. Radio	602.000 MHz	6900	10434	1039	41028
131	SWR Aktuell	ARD SWR	dig. Radio	602.000 MHz	6900	10447	1039	41028
132	SWR1 BW	ARD SWR	dig. Radio	602.000 MHz	6900	10440	1039	41028
133	SWR1 RP	ARD SWR	dig. Radio	602.000 MHz	6900	10441	1039	41028
134	SWR2	ARD SWR	dig. Radio	602.000 MHz	6900	10442	1039	41028
135	SWR3	ARD SWR	dig. Radio	602.000 MHz	6900	10443	1039	41028
136	SWR4 BW	ARD SWR	dig. Radio	602.000 MHz	6900	10444	1039	41028
137	SWR4 RP	ARD SWR	dig. Radio	602.000 MHz	6900	10445	1039	41028
138	WDR 2 Rheinland	ARD WDR	dig. Radio	602.000 MHz	6900	10452	1039	41028
139	WDR 3	ARD WDR	dig. Radio	602.000 MHz	6900	10453	1039	41028
140	WDR 4	ARD WDR	dig. Radio	602.000 MHz	6900	10454	1039	41028
141	WDR 5	ARD WDR	dig. Radio	602.000 MHz	6900	10455	1039	41028
142	WDR Event	ARD WDR	dig. Radio	602.000 MHz	6900	10459	1039	41028
143	ANTENNE BAYERN	BetaDigital	dig. Radio	642.000 MHz	6900	170	7	41028
144	ROCK ANTENNE	BetaDigital	dig. Radio	642.000 MHz	6900	160	7	41028
145	Sunshine live	BetaDigital	dig. Radio	642.000 MHz	6900	169	7	41028